




Spare Parts List Mounted return line filter RFD

up to 1300 l/min, up to 25 bar



1. MAINTENANCE

1.1 GENERAL

Please follow the maintenance instructions!


1.2 INSTALLATION

Before fitting the filter into the system, check that the operating pressure of the system does not exceed the permitted operating pressure of the filter.

Refer to the name plate on the filter!

1.3 COMMISSIONING

Check that the correct filter element is fitted. Fit cover and screw in cover bolts alternately. Move the lever to the centre position and fill filter via the system (both filter sides are filled).



After that, change over to a filter side by throwing the lever to one filter side and check filter for damage.

1.4 TOOLS REQUIRED FOR MAINTENANCE

Size	Torque value	Int. hex. Allen key
60/110	20 Nm	AF width 6
160/240	20 Nm	AF width 6
330	40 Nm	AF width 8
660	150 Nm	AF width 14
950/1300	200 Nm	AF width 17

1.5 TORQUE VALUES FOR CLOGGING INDICATORS

Type	Max. torque
VR	33 Nm (for RFD 60-330) 50 Nm (for RFD 660-1300)
VR	15 Nm (for B, BM F, LE and LZ indicators)

2 CHANGING THE ELEMENT

2.1 REMOVING THE ELEMENT

1. Switch lever slowly over to clean filter side.

Caution: when fitted inline:

Before opening the filter, slowly open the air bleed screw and release pressure (release possible pressure in the tank).

2. Size 60-330:

Loosen cover bolts and lift off cover.

Size 660-1300:

Unscrew cover bolts by approx. 2 turns (no need to remove completely). Turn cover clockwise until it can be lifted off by holding near the bolts (bayonet).

3. Pull out filter element(s) (with dirt retainer – if present) by the handle. Examine element surface for dirt residues and larger particles since these can be an indication of damage to components.

4. Remove dirt retainer (if present) by turning anti-clockwise – bayonet fitting.

5. Replace or clean filter element(s) (only W/HC and V elements can be cleaned).

6. Clean housing, cover and dirt retainer.

7. Examine filter, especially sealing surfaces, for mechanical damage.

8. Check O-rings – and replace if necessary

2.2 FITTING THE ELEMENT

1. Lubricate the sealing surfaces on the filter housing and cover, as well as the O-ring, with clean operating fluid.

2. When fitting a new filter element, check that the designation corresponds to that of the old element.

3. If present, fit the dirt retainer onto the new or cleaned filter element by turning clockwise.

4. Place filter element(s) carefully on to the element spigot in the housing.

5. Size 60-330:

Position cover and screw in cover bolts by hand; then tighten the cover bolts in alternation.

Size 660-1300:

Replace cover in correct position (dowel pin in the housing must line up with groove in the cover) and turn anti-clockwise as far as it will go. Tighten cover bolts alternately.

6. Vent filter at an appropriate point in the system.


7. Check the filter for leakage.

NOTICE:

Filter elements which cannot be cleaned must be disposed of in accordance with environmental protection regulations.

3. SPARE PARTS

3.1 SPARE PARTS DRAWING RFD 60 – 1300



3.2 SPARE PARTS LIST RFD 60 – 1300

Item	Con-sists	Description	RFD 60	RFD 110	RFD 160	RFD 240	RFD 330	RFD 660	RFD 950	RFD 1300
1.		Filter element	see Point 4. Replacement elements							
	1.1	Filter element	0060 R...	0110 R...	0160 R...	0240 R...	0330 R...	0660 R...	0950 R...	1300 R...
	1.2	O-ring	22 x 3.5		34 x 3.5		48 x 3	68 x 5	97.8 x 5.33	
2.		Clogging indicator or screw plug	See Point 5. Replacement clogging indicator							
	2.1	Screw plug VR 0 A.0 VR 0 A.0 /-V	00306006 00305928							
	2.2	O-ring	18 x 2.5							
3.		Seal kit RFD Seal kit RFD /-V	2 x 01267827 2 x 01267828	2 x 01270657 2 x 01270658		2 x 00319613 2 x 00311702	2 x 01293036 2 x 01293033	2 x 01293037 2 x 01293034		
	3.1	O-ring (element)	22 x 3.5	34 x 3.5		48 x 3	68 x 5	97.8 x 5.33		
	3.2	O-ring (cover)	63.09 x 3.53	91.67 x 3.53		105 x 5	153 x 5	185 x 5		
	3.3	O-ring (indicator)	18 x 2.5							
	3.4	O-ring (tank seal)	82.14 x 3.53	110.72 x 3.53		00405588	03170653	00405590		
4.*		Dirt retainer RF/D...	00245028	00246164	00245029	00246182	00245030	00245031	00413196	-
		Dirt retainer RF/D...HC	01202362		01202363		01202364	01202357	01204141	
5.		Lever RFD...	00270382				00270383		01205525	

*if present
Other spare parts on request

4. REPLACEMENT ELEMENT

0330 R 010 ON /-V

Size

0060, 0110, 0160, 0240, 0330, 0660
0950, 1300

Type

R

Filtration rating

ON: 001, 003, 005, 010, 015, 020
V: 003, 005, 010, 020
W/HC: 025, 050, 100, 200
P/HC: 010, 020
BN4AM: 003, 010
AM: 040

Filter material

ON, V, W/HC, P/HC, BN4AM, AM

Supplementary details

V (For description see "RFD" brochure)

5. REPLACEMENT CLOGGING INDICATOR

VR 2 D . X /-L24

Type of indicator

VR Return line pressure indicator

Response pressure

2 standard 2 bar, others on request

Type of clogging indicator

A with screw plug in indicator port
B visual
C electrical
D visual and electrical

Modification number

X the latest version is always supplied

Supplementary details

L..., LED, V, W
(for description, see "Clogging Indicators" brochure)

6. MAINTENANCE INSTRUCTIONS

6.1 USER INSTRUCTIONS FOR FILTERS



Notice

This pressure equipment must only be put into operation in conjunction with a machine or system.



Notice

The pressure equipment must only be used as stipulated in the operating instructions of the machine or system.



Notice

This pressure equipment must only be operated using hydraulic or lubricating fluid.



Caution

The user must take appropriate action (e.g. venting) to prevent the formation of air pockets.



Caution

Repair, maintenance work and commissioning must be carried out by specialist personnel only.

Allow the pressure equipment to cool before handling.

The stipulations of the operating instructions of the machine or system must be followed.



Danger

Caution: pressure equipment! Before any work is carried out on the pressure equipment, ensure the pressure chamber concerned (filter housing) is depressurised.



Danger

On no account must any modifications (welding, drilling, opening by force etc.) be carried out on the pressure equipment.



Notice

It is the responsibility of the owner to comply with the water regulations of the country concerned.



Caution

Statutory accident prevention regulations, safety regulations and safety data sheets for fluids must be observed.



Caution

Filter housing must be earthed.



Caution

When working on, or in the vicinity of, hydraulic systems, naked flames, spark generation and smoking are forbidden.



Caution

Hydraulic oils and water-polluting fluids must not be allowed to enter the soil or watercourses or sewer systems. Please ensure safe and environmentally friendly disposal of hydraulic oils. The relevant regulations in the country concerned with regard to ground water pollution, used oil and waste must be complied with.



Caution

Whenever work is carried out on the filter, be prepared for hot oil to escape which can cause injury or scalding as a result of its high pressure or temperature.



Danger

When using electrical clogging indicators, the electrical power supply to the system must be switched off before removing the clogging indicator connector.

Customer Information in respect of Machinery Directive 2006/42/EC

Hydraulic filters are fluid power parts/ components and are therefore excluded from the scope of the Machinery Directive. They do not bear the CE mark. Before using these components, ensure compliance with the specifications provided by HYDAC Filbertechnik GmbH in this documentation.

The specifications also contain information on the relevant essential health and safety requirements (based on Machinery Directive 2006/42/EC) that are to be applied by the user.

We hereby declare that the filters are intended to be incorporated into machinery within the terms of the Machinery Directive 2006/42/EC. It is prohibited to put the filters into service until the machinery as a whole is in conformity with the provisions of the Machinery Directive. Furthermore, our Terms of Sale and Delivery are available on our website (www.hydac.com).

SERVICE ADDRESSES

HYDAC Service GmbH
Postfach 1251
66273 Sulzbach / Saar, Germany

Factory address:

Werk 13
Friedrichsthaler Str. 15
66540 Neunkirchen / Heinitz
Germany

ServiCenter:

Tel.: +49 (0) 6897 / 509-9083
Fax: +49 (0) 6897 / 509-9881

Customer service:

Tel: +49 (0) 6897 / 509-412
Fax: +49 (0) 6897 / 509-828

6.2 MAINTENANCE, GENERAL

This section describes maintenance work which must be carried out periodically. The operational safety and life expectancy of the filter, and whether it is ready for use, depend to a large extent on regular and careful maintenance.

6.3 MAINTENANCE MEASURES

- Spare parts must fulfil the technical requirements specified by the manufacturer.
This is always guaranteed for original HYDAC spare parts.
- Keep tools, working area and equipment clean.
- After disassembling the filter, clean all parts, check for damage or wear and replace parts if necessary.
- When changing a filter element, a high level of cleanliness must be observed!

6.4 INTERVAL BETWEEN ELEMENT CHANGES

In principle we recommend that the filter element is changed after 1 year of operation at the latest.

When no clogging indicator has been fitted, we recommend changing the elements at specific intervals. (The frequency of changing the filter elements depends on the filter design and the conditions under which the filter is operated.) When filter elements are subject to high dynamic loading it may prove necessary to change them more frequently. The same applies when the hydraulic system is commissioned or repaired or when the oil is changed.

The standard clogging indicators only respond when fluid is flowing through the filter. With electrical indicators the signal can also be converted into a continuous display on the control panel. In this case the continuous display must be switched off during a cold start or after changing the element.

If the clogging indicator responds during a cold start only, it is possible that the element does not yet need to be changed.

NOTE

The information in this brochure relates to the operating conditions and applications described. For applications or operating conditions not described, please contact the relevant technical department. Subject to technical modifications.