

CTU 2000 — Supplemental Instructions

These supplemental instructions are valid only in conjunction with the Operating and Maintenance Manual Doc: 3160738

In contrast to the Operating and Maintenance Manual (section 6.10), a manual shut-off has been additionally included on the CTU 2000 for the automatic rinsing fluid reservoir switchover.

You can prevent automatic rinsing fluid changeover by deactivating it.

Switch turned to the left: automatic rinsing fluid changeover activated

Switch turned to the right: automatic rinsing fluid changeover deactivated



Note the Operating and Maintenance Manual.