



### Updating the device for the use with USB 3.0

If you wish to update a hydac measuring device (e.g. HMG 510, HMG 3000, CMU 1000) for the use with USB 3.0.

#### Condition:

1. PC with USB 2.0 interface
2. Administration rights are required

#### Procedure:

Please follow the below mentioned instructions:

1. Please install the HE Virtual Comport Driver 5.3:  
[HE-Virtual Comport Driver V5.3.zip](#)(For the Zip file, please proceed as follows: download the file to local directory, unpack, execute HE-Virtual-Comport-Installer.exe)

Restart your PC

2. Install the Silabs driver:  
Version for Windows 2000: [CP210x\\_VCP\\_Win2K.exe \(4,79 MB\)](#)  
Version for current operating systems: [CP210x\\_VCP\\_Win\\_XP\\_S2K3\\_Vista\\_7.exe \(6,78MB\)](#)  
(This file is opened immediately)

Restart your PC

3. Connect the device to the PC (should you have further devices which need an update, this must be carried out one device after the other. For the update, never have more than one device connected to the PC)
4. Open the USB3Update:  
[USB\\_Driver\\_3.0 \(540 kB\)](#) (For the Zip file, please proceed as follows: Download the file to local directory, unpack, execute USB3Update.bat)  
if the device is recognised, please confirm with "yes" and start the update with <ENTER>.